

Wear Motobit SENTINEL on your arm, under your glove or in a pocket and receive safety-related information intuitively while riding your motorcycle via the paired MOTOBIT APP using a strong vibration feedback without distractions.



TECHNICAL INFORMATION

Model: SentinelOne Battery: Li-Ion 3.7V 100mAh Power supply voltage/amperage: 5V/90mA

Notch (Sleeve) **Button with integrated LED** \bowtie Charging connector (Back) Detachable wristband

Dimensions: 23,2cm x 2,2cm (incl. wristband) Connection: **Bluetooth 5.0 LE** Platform: Android 8.1+

PACKAGE CONTENTS

- Motobit SENTINEL
- Wristband (22mm with quick-release)
- USB charging cable
- Quick-start guide



1. FULLY CHARGE SENTINEL BEFORE FIRST USE

The LED will flash green when charging and turns off when complete.

- 2. DOWNLOAD THE MOTOBIT APP AND SET UP YOUR PROFILE
- 3. PRESS THE SIDE BUTTON ON SENTINEL TWICE TO WAKE IT UP

The device will vibrate shortly, start flashing blue, and will be available to connect for 60 seconds.

4. GO TO SENTINEL PREFERENCES (APP SETTINGS)

Check if SENTINEL is already connected, otherwise press "Connect" in the settings or "Pair" if asked. When connected successfully, SENTINEL will both vibrate and glow green shortly.



MANUAL CONNECTION

IF A CONNECTION BETWEEN SENTINEL AND THE SMARTPHONE CANNOT BE ESTABLISHED VIA SETUP, IT IS POSSIBLE TO ESTABLISH THE CONNECTION MANUALLY.

- 1. Make sure that your Sentinel is in pairing mode (see point 3 under SETUP).
- 2. Go to the Bluetooth settings of your smartphone.
- 3. Select "Pair new device". Sentinel" should appear among the available devices.
- 4. After "Sentinel" is selected, the connection is automatic and confirmed by a short vibration.
- (5. By selecting "Sentinel" again, the pairing can be disconnected via the "Forget" icon).

NOTE:

- With some smartphones, it is possible that the connection is only made through "Connect" after "Sentinel" has been selected from the available devices.
- In case the manual connection setup generates an error message, please try again.
- In certain cases, it is possible that SENTINEL is marked as not connected in the Motobit APP despite a manual connection having already been made. This can be remedied by dissolving the connection (see point 5) and then reconnecting manually.



CHARGING

CONNECT THE INCLUDED CHARGING CABLE WITH SENTINEL AND PLUG IT INTO A USB PORT

The LED will flash green when charging. Check the battery level on top of the HOME tab or Sentinel configuration in the APP settings.

IMPORTANT: Ensure to DISCONNECT the charging cable when not used.



BEFORE RIDING

CHECK IF SENTINEL IS CONNECTED IN THE INFO AREA ON TOP OF THE HOME TAB BEFORE TRACKING YOUR NEXT RIDE If not, wake up Sentinel by pressing the button twice to reconnect. The device will vibrate shortly when pressing START to indicate it is active during your next ride.

SET THE SENTINEL SIGNAL SLIDER IN THE DESIRED APP-FEATURE

Choose which app feature you want to use with SENTINEL by enabling the Sentinel signal slider.



AFTER RIDING

ENERGY-SAVING MODE

SENTINEL will switch to energy-saving mode after 60 seconds when being disconnected from any smartphone. **MAINTENANCE**

SENTINEL can be cleaned with a slightly moistened cloth. Please be advised, not to use aggressive chemicals so that no damage will get caused to the housing material. To clean SENTINEL easily, it is recommended to detach the wristband from the device.



ATTENTION

- SENTINEL is NOT waterproof, please ensure to use it in a dry environment and do not expose it to moisture.
- Make sure to keep SENTINEL away from heat sources and do not expose it to a open flame, otherwise the battery may be damaged. Avoid storing it in an environment with a temperature above 50°C.
- ALWAYS use the original charging cable provided for proper charging.

WARRANTY AND CONTACT

Motobit SENTINEL includes a <u>2-year manufacturer's warranty</u> on the device (excl. wristband) from the date of purchase and invoice.

Contact us if you have any questions about SENTINEL: support@getmotobit.com feedback@getmotobit.com Send us your feedback to improve SENTINEL:



CONFORMITY

Hereby motobit GmbH declares that the radio equipment type **SentinelOne** is in compliance with **Directive 2014/53/EU**.



LEGAL INFORMATION

The use of both the MOTOBIT APP and SENTINEL does not relieve the user from maintaining a thoughtful drive in compliance within the framework of existing road traffic legislation and rules. You agree that you have read, understood, and agree to be bound by all of the Terms and Conditions Use. More information about our Terms and Conditions can be found here: https://www.getmotobit.com/terms-of-use/

The user also acknowledges that the services provided by MOTOBIT do not in any way substitute the compliance of the applicable road traffic regulations and can not be held responsible for any violation attributed to the user. MOTOBIT is exempted from all contractual and/or non-contractual liability for direct and/or indirect damages suffered by the customer and/or third parties as a result of negligence or violation of the road traffic regulations. Hence, MOTOBIT will not be liable for any sanctions that may arise against the use of the MOTOBIT service in the event of driving negligence or violation of the road traffic regulations.



